

Saratoga Sigilla Bagno – Seal Bathroom

Saratoga Sigilla Bagno is a butyl-based thermoplastic adhesive sealant that looks like a preformed self-adhesive plastic tape.

APPLICATION FIELDS

Ideal for sealing between wall and bathtub or between wall and shower tray, it can be easily applied quickly, is mould-resistant, can be cleaned simply with a damp cloth, does not crack or discolour, and can even be applied to old seals. Suitable for straight stretches (do not use on curves).

APPLICATION

- Thoroughly clean with alcohol or abrasive cleaner the area between the wall and the tub or shower tray, where the tape should adhere.
- Surfaces must be perfectly dry; there is no need to remove the old sealant if it does not interfere with the contact areas of the adhesive part of the tape.
- Fill any irregularities in the surfaces, especially in case of deep joints.
- Apply at temperatures not below +10°C (the tape must also be kept at a temperature >+10°C before use).
- Cut Saratoga Sigilla Bagno to the exact size of the joint to be sealed.
- Before applying Sigilla Bagno, fold it over preparing it for insertion and thus counteracting the memory effect of the rubber.
- To increase the flexibility of the product, heat it with a normal hair dryer, in this way Sigilla Bagno will be more malleable and easier to apply.
- Fold it over its full length and remove the first 10 cm of the protective film. Apply the 90 degree folded tape on the joint line, where the wall matches the edge of the sanitary fitting and press down firmly. Continue separating the protective film from the tape until the joint is complete.
- In case of corner sanitary ware, apply the tape in the same way on the other side of the sanitary ware, overlapping the two parts of the tape on the corner. You can leave it as it is, or cut both lower parts of the ribbon in the middle, to make them fit perfectly together (like the corners of frames).
- After application, press firmly again on the entire surface of the tape to ensure maximum adhesion.
- Protect from water and wait 24 hours before using the sanitaryware. Before use, check that the product adheres well.

Specific data		
Colour	White	
Hardness	40-45 Shore D	According to DIN ISO 7619-1
Density	1.03 g/cm ³	According to DIN EN ISO 1183-1
Tensile strength	19 +0.5 MPa	Based on DIN 53504/ISO 37
Elongation at break	>700 %	Based on DIN 53504/ISO 37
Complete hardening after	24 h	

STORAGE AND SHELF LIFE

In unopened original packaging, between +20 and +25°C.

CAUTIONS

Keep out of the reach of children.

Consult Material Safety Data Sheet for full list of hazards and the directions on the product label itself.

For further information, please visit our site www.saratoga.it

Product Description	Pack size	Product code	Box quantity	EAN Code
Sigilla Bagno in case	mm 22 x 335 cm	57 415 001	12	8 005860 574151
Sigilla Bagno in blister pack	mm 22 x 335 cm	57 416 001	12	8 005860 574168



12/15/2021, 3rd Rev - The technical data contained herein is based on our present knowledge and experience and we cannot be held liable for any errors, inaccuracies, omissions or editorial failings. All the information herein do not involve the assumption of responsibility in case of damages. Before using the product, the user should carry out any necessary test in order to ensure that the product is suitable for the intended application. All users should contact the seller or the manufacturer of the product for additional technical information concerning its use if they think that the information in their possession needs to be clarified in any way, for specific features, please contact Saratoga Int Sforza spa. Our specialists are at your disposal for further information. needs to be clarified in any way, for specific features, please contact Saratoga Int Sforza spa. Our specialists are at your disposal for further information.